

Mountaintech FX Nytro Shorty Skid plate Installation



1. Raise the front of the sled and support it adequately so that you can work under it safely.
2. Remove hood, side panels, lower side panels, and finally the factory plastic skid plate.
3. Enlarge the 4 lower mounting holes to 3/8" with a 3/8" drill bit. Deburr the holes and snap in the 4 Unuts, flat side down.
4. Install the 8mm bolt in the top hole with the threads facing forward. (A telescopic magnet, 1/4" drive ratchet with 6" extension, swivel adapter and 13mm socket gets the job done) Secure the bolt with the shouldered nut. Loctite and torque to 20 ft/lbs. Install 1 flat washer on bolt after tightening nut.
5. Install Mountaintech Shorty Skid plate with remaining hardware.
6. Reinstall plastic body panels

Disclaimer: Use this product at your own risk! Mountaintech Industries is not liable, or responsible in any way for any damage, or injury to you, your passenger, or your snowmobile from installation of this device.